

- i. *Fire Pump should not be activated, where applicable.*
 - 1) *When activated, the Fire Pump is loud, so the responsible party will be aware if it is activated.*
- ii. *If Fire Pump is activated, please notify TUPD, EHS, or BFPE.*

- 2) *EHS Fire Safety Manager, Justin Basnight – 404-449-9712*
- 3) *BFPE, Steve Hale – 410-409-0995*
- 4) *BFPE, Andy Twig – 443-277-4796*

